


## Exploded View of Model 87 Icer-ette

FIG 1



### Item Part # Description

FIG 1

- 1 87201W Top and bottom hinge includes part #7 (FIG 1)
- 2 872021 Icemaker 115V  
872022 Icemaker 230V
- 3 87203W Handle Latch Assy. includes part #4 (FIG 1)
- 5 87205 S/S Door Assy.
- 6 87206 Power Switch
- 8 87209 Ice Bucket
- 9 872111 Water Valve 120V AC  
872112 Water Valve 230V AC
- 10 87215 Cold control

### Not Shown:

- 872131 Compressor w dryer 120V
- 872132 Compressor w dryer 230V
- 872441 Fan motor 120V
- 872442 Fan motor 230V

FIG 2

- 1 872021 Icemaker Assy. 115V  
872022 Icemaker Assy. 230V
- 2 872021M Motor Assy. faceplate 115V  
872022M Motor Assy. faceplate 230V

FIG 2




FIG 3

- 1 872113 Water Connector
- 2 872114 Water Hose
- 3 872111 Water Valve 120V  
872112 Water Valve 230V
- 4 872115 Water Outlet Connector
- 5 872116 Water Line Black Rubber Seal
- 6 872117 Water Line Plastic Buckle
- 7 872118 Water Supply Connector 2
- 8 872119 Water Supply Connector 1

FIG 3

